Customizing Your Lexus

Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and can be performed by an authorized Lexus dealership.

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

| ltem | Function | Default setting | Customized setting |
|-----------------------------|---|--|--------------------------------------|
| Smart access system with | Operation signal (Emergency flashers) | On | Off |
| push-button start | Operation signal (Buzzer) | On | Off |
| | Unlocking operation | Driver's door unlocked in one step, all doors unlocked in two steps | All doors unlocked in one step |
| | Automatic door lock function to be activated if door is not opened after being unlocked | On | Off |
| Wireless remote | Time elapsed before automatic door lock function is | 60 seconds | 30 seconds |
| control | activated if door is not opened after being unlocked | oo seconas | 120 seconds |
| | Operation signal (Emergency flashers) | On | Off |
| | Operation signal (Buzzer) | On Off | |
| | Door lock buzzer | On | Off |
| | Trunk unlocking function | On | Off |
| | Trunk unlocking operation | Push and hold | Push twice One short push |
| | Panic function | On | Off |

Customizing Your Lexus

| ltem | Function | Default setting | Customized setting |
|-----------------|--|--|--------------------------------------|
| | Unlocking using a key | Driver's door unlocked in one step, all doors unlocked in two steps | All doors unlocked in one step |
| Door lock | Speed-detecting automatic door lock function | Off | On |
| | Opening driver's door unlocks all doors | Off | On |
| | Shifting gears to P unlocks all doors | On | Off |
| | Shifting gears to position other than P locks all doors | On | Off |
| Steering wheel | Auto tilt-away function | On | Off |
| | Linked door lock operation | On | Off |
| Power windows | Linked door key operation | Open and close | Open only Close only |
| | Wireless remote control linked operation | Off | Open only |
| | Linked door lock operation | On | Off |
| | Linked door key operation | Open and close | Open only Close only |
| Moon roof | Linked operation of components when door key is used | Slide only | Tilt only |
| 1 100111001 | Wireless remote control linked operation | Off | Open only |
| | Linked operation of components when wireless remote control is | Off | Slide only |
| | used | OII | Tilt only |
| | Light sensor sensitivity | Level 3 | Level 1 to 5 |
| Automatic light | Time elapsed before headlights | 30 seconds | 0 seconds |
| control system | automatically turn off after | | 60 seconds |
| | doors are closed | | 90 seconds |
| Lights | Daytime running light system (U.S.A. only) | On | Off |

| ltem | Function | Default setting | Customized setting |
|-----------------------|---|--|---------------------------|
| | Switching operation when the vehicle is stationary | On | Off |
| Windshield | Drip prevention function | On | Off |
| wipers and washer | Time elapsed before the drip prevention function operates | Variable depending on the vehicle speed | 3 seconds |
| Intuitive parking | Back sensor operation display and buzzer | On | Off |
| assist | Buzzer volume | Level 3 | Level 1 to 5 |
| | Distance which a sensor detects | 4.9 ft. (150 cm) | 2.0 ft. (60 cm) |
| | Time elapsed before lights turn off | 15 seconds | 7.5 seconds 30 seconds |
| | Operation when the doors are unlocked | On | Off |
| Illumination | Operation after the "ENGINE START STOP" switch turned OFF | On | Off |
| | Front foot well lights | On | Off |
| | Shift lever light | On | Off |
| | Outer foot light | On | Off |
| Seat belt reminder | Vehicle speed linked seat belt reminder buzzer | On | Off |

| M | emo | |
|---|-----|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

| Memo | |
|------|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| M | emo | |
|---|-----|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |



Your Lexus dealer

Your Lexus dealer will provide quality maintenance and any other assistance you may require.

If there is not a Lexus dealer near you, please call the following number:

n U.S. OWNERS

- In the U.S. mainland or Canada:
 Lexus Roadside Assistance
 1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)
- 1 In Hawaii:

Servco Automotive Roadside Assistance/Customer Services 1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)

n CANADIAN OWNERS

In Canada or the U.S. mainland:
 Lexus Roadside Assistance/Customer Service
 1-800-26-LEXUS or 1-800-265-3987 (Toll-Free)

Please access our websites for further information.

- 1 The U.S. mainland: www.lexus.com
- 1 Hawaii: www.servcolexus.com
- 1 Canada: www.lexus.ca

©2009 TOYOTA MOTOR CORPORATION

All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of Toyota Motor Corporation.